

ES 250 PRO Easy

Montaj talimatları

060521-45532/17606 – 02/2024

EN

Contents

1	About this document	4
1.1	Contents and purpose	4
1.2	Target group	4
1.3	Other applicable documents	4
1.4	Documents storage	4
1.5	Abbreviations	4
1.6	Symbols used	5
2	Safety	6
2.1	Intended use	6
2.2	Improper use	6
2.3	Reasonably foreseeable misuse	6
2.4	Risk assessment	6
2.5	Basic warnings	6
3	Product description	7
3.1	Overview	7
3.2	Operating elements	8
3.3	Parts included	9
3.4	Technical data	9
3.5	Closing edge protection	9
3.6	Secondary closing edge protection	9
4	Mounting	10
4.1	Safety during mounting	10
4.2	Requirements for mounting	10
4.3	Mounting the operator	11
4.4	Mount the optional side panels	23
4.5	Mount the optional anti-static brushes	24
4.6	Mount the carriers	24
4.7	Hook in the door leaf	25
4.8	Mount the floor guides	26
4.9	Align the door leaves	26
4.10	Adjust the opening width	29
4.11	Mount the toothed belt engaging units	30
4.12	Mount the optional locking device	31
4.13	Mount the DRIVE UNIT	31
4.14	Mount the tensioning device	33
4.15	Cut the toothed belt to size	33
4.16	Mount the toothed belt	33
4.17	Adjust the tensioning device	37
4.18	Position the main closing edge	37
4.19	Mount the cable ducts	38

4.20	Mount the cover holders	38
4.21	Prepare the internal cover	39
4.22	Mount the internal cover	40
4.23	Mount and connect the accessories	43
4.24	Position the sensors	44
5	CAN BUS system (only for EPS CAN)	46
5.1	CAN BUS components	46
5.2	Properties of CAN BUS systems	46
5.3	Connecting a CAN BUS component	47
6	Terminal layout	48
6.1	Terminal layout of the control board	48
6.2	Multiports	50
7	Connection of sensors	52
8	Commissioning	53
8.1	Requirements	53
8.2	Safety during commissioning	53
8.3	Commission the operator	53
9	Fire protection function	56
9.1	Activate the fire protection function	56
10	Parameterization	57
10.1	Change parameters	57
10.2	Parameter overview	57
11	Information and error display	63

1 Product description

1.1 Overview




Fig. 1

- | | |
|---------------------------|---|
| (1) Carriers | (19) Rubber strip |
| (2) Engaging unit | (20) Track profile |
| (3) Operator profile | (21) Counter roller |
| (4) Battery | (22) Anti-static brush |
| (5) Toothed belt | (23) Adjustable brackets |
| (6) Mounting profile | (24) Carriers with engaging unit for
1-leaf units |
| (7) LM girder | (25) Bag of screws:
17508901150 for 2-leaf units
17509001150 for 1-leaf units |
| (8) End stop | |
| (9) Locking device | |
| (10) DRIVE UNIT | |
| (11) End plate | |
| (12) Logo clip | |
| (13) Cover holders | |
| (14) Internal cover | |
| (15) Door Pilot Interface | |
| (16) Cable duct | |
| (17) Hinge profile | |
| (18) Deflection device | |

1.2 Operating elements

The control unit has a user interface with 4 keys and a 2-digit display.




Fig. 2

The following functions can be executed by pressing the keys:

- | | |
|--|--|
| <p>▶ Right key</p> <ul style="list-style-type: none"> • Open parameters menu • Display parameter value • Select parameter to be changed • Save changed parameter value • Open error menu | <p>▼ Bottom key</p> <ul style="list-style-type: none"> • Scroll through parameters and error messages • Decrease the parameter value • Opening impulse • Teach-in run (press for 3 secs) • Factory reset (Fact-Setup) (press for 8 secs) |
| <p>◀ Left key</p> <ul style="list-style-type: none"> • Close change parameters • Close parameters menu • Close error menu • Stop service mode (press for 3 secs) | <p>▲ Top key</p> <ul style="list-style-type: none"> • Scroll through parameters and error messages • Increase the parameter value |
| <p>◀ ▶ Press left and right key at the same time</p> <ul style="list-style-type: none"> • Error acknowledgement • Reset (press for 3 secs) | |

1.3 Parts included

The parts included are stated on the delivery note. Fixing materials such as dowels and screws are not included.

1.4 Technical data

Connection voltage:	230 V 50 Hz +10%/-15%
Fuse supplied by the customer:	10 A
Protection class:	IP 20
Permissible humidity:	93% relative humidity, non-condensing
Operating temperature:	↕ -20°C to ↕ +60°C
Power supply for external devices	
- for mains operation:	27 V DC/max. 1 A short-circuit-proof
- in the event of a mains failure in battery mode:	27 V DC/max. 1 A short-circuit-proof
Multiport inputs	27 V ±15 %

1.5 Closing edge protection



Warning

Only safety sensors with type approval according to EN 16005 may be used!

1.6 Secondary closing edge protection

If the distance of the opened door leaf to a stationary obstacle (e.g. a wall) is smaller than 200 mm, the secondary closing edge must be protected, for example with safety sensors or a protective panel.

2 Terminal layout

2.1 Terminal layout of the control board





Fig. 78

- | | |
|--|-----------------------------------|
| (1) Terminal block | (5) Power supply connection |
| (2) Operator locking device connection | (6) Battery pack connection |
| (3) COM port | (7) Drive connection |
| (4) CAN BUS port | (8) Hall effect sensor connection |

Power supply 27 V	27 V	1E	41	3	12	1E	3	16	15	1E	17	3	33	34	3	Power supply 27 V
Inside activation (radar detector)	ACT IN															ACT OUT
	GND															GND
Safety bumper input MCE 1	SAFE MCE 1															SAFE MCE 2
Power supply 27 V	27 V	1E	42	3	11	1E	13	3	1E	101	102	3	30	31	32	Power supply 27 V
MCE test output	TEST MCE															GND
	GND															GND
Power supply 27 V	27 V															SAFE SCE 2
Multiport input/output 1	IO1															SAFE SCE 1
Multiport input/output 2	IO2															Power supply 27 V
	GND															TEST SCE
	GND															GND
Operating mode Off	OFF															PART OPEN
Automatic operating mode	AUTO															OPEN
Operating mode output	EXIT															Permanent open operating mode
	GND															GND



The terminal block is located on the left side of the Drive Unit.

Fig. 79

2.2 Multiports

The multiports are used to connect components to the control unit.

The multiports can be configured individually as input (high/low active, normally open/normally closed) or as output (open collector) via the OSI.

The multiports can be parameterized via the parameters u1 and u2.

The level can be parameterized via the parameters n1 and n2.

I/O 2 = Multiport 2 and Wake-Up

In battery mode, the control unit switches to energy-saving mode. The control unit can only be activated via Multiport 2.

2.2.1 Possible functions

The following functions can be configured via the OSI.

Exit	<ul style="list-style-type: none"> • Status "Door closed" • Status "Door open" • Malfunction • Status "Door closed and locked" • Info and malfunction 	<ul style="list-style-type: none"> • Doorbell contact • Lock alarm • Status "No faults in unit" • Service LED
Input	<ul style="list-style-type: none"> • Night/bank • Key switch 1 left • Key switch 1 right 	<ul style="list-style-type: none"> • Soft reset • Fire protection closures

Factory setting

Multiport 1 (I/O1) = Door closed

Multiport 2 (I/O2) = Night/bank

2.2.2 Connection on the multiports

27 V DC doorbell connection




Fig. 80

Night/bank connection




Fig. 81

Connection for "Door closed" message potential-free




Fig. 82

Connection for "Door closed" message 27 V DC




Fig. 83

Key switch connection




Fig. 84

Operating mode switch connection




Fig. 85

3 Commissioning

3.1 Requirements

- The operator is mounted correctly, mechanically and electrically.
- The area of movement of the door leaf is free from obstacles.
- The door is in the half-open position.
- The safety sensor connections on the terminal block are bridged.
- The operating mode switch is in Off mode.

3.3.1 Service mode

In Service Mode 1, the sensors are not evaluated by the control unit.

In Service Mode 2, the CAN components are not evaluated by the control unit.

If a Service Mode is activated, all errors are acknowledged and the closing movements run at crawl speed.

Display

1. Connect the power supply unit to the power supply, and, if present, the battery.

- ▶ The control unit carries out a self-test.



- ▶ The device identification is shown on the 2-digit display as "ES" followed by "EASY" and the "Firmware version".

ES XXX F 1 0 000

Control unit:


EASY = Easy control unit

- ▶ The CAN BUS is initialized.



- ▶ The small, spinning "o" and the "P" show that parametrization is required.
- ▶ The control unit switches to Service Mode 2.



2. Press  for 3 seconds to open the parameters menu.
3. Set the parameters "L1" and "dL", see "10 Parameterization".
4. If an EPS CAN is used, set the parameter "PS" to the value 4 .

Display

5. ◀ Press to exit the parameters menu.

- ▶ The small, spinning "o" and the "O" show that a teach-in run is required.



6. ▼ Press for 3 seconds.

- ▶ The door moves in closing direction to determine the closed position.



- ▶ The door carries out a teach-in run.
- ▶ The door closes.



- ▶ The door is pushed into closed position.
- ▶ An existing interlock is taught in.



- ▶ The door leaf weight is calculated.



- ▶ The door moves at crawl speed in opening direction.



- ▶ The opening width and the door leaf weight are saved.



- ▶ The operator moves into closed position.
- ▶ The teach-in run is finished, the control unit switches to Service Mode 1.



7. ◀ Press for 3 seconds to exit Service Mode 1.

→ **Commissioning is complete, the operator is ready for operation.**

8. If safety sensors are to be connected to the terminal block, connect the safety sensors and set the parameter **5f** accordingly.

4 Fire protection function

The fire protection function enables the sliding door to close safely in case of fire. The function is controlled externally, e.g. via fire alarm systems or building management systems. A rechargeable battery is required for the function.

4.1 Activate the fire protection function

1. Connect the external control unit for the fire protection function to the multiport I/O.
2. Activate the fire protection function via the "P" parameter.
3. Configure the multiport for fire protection.

When the parameter "P" is set to the fire protection function, the following functions/parameters are changed:

Parameter	Is changed to	Can be changed subsequently
Obstacles in Open	5	yes
Obstacles in Closed	5	yes
Blocking function	Door stops	yes
Night/bank configuration	Edge	no
Power saving mode	is ignored	no
Waiting time at the obstacle in closing direction	5 seconds	no

When the fire protection function is triggered, the door closes and is locked.

The door moves at creep speed due to the deactivated sensor system.

The following functions are no longer possible:

- Opening the door via the sensor system
- Change of the operating mode

Opening the door is now only possible via the night/bank impulse.

5 Parameterization

After carrying out a teach-in run, the operator can be operated with the basic parameters.

The system offers the option to adapt the travel parameters to the actual conditions as well as to activate advanced functions. These parameters should be set during commissioning according to the customer's wishes.




Fig. 86

5.1 Change parameters

1. **▶** Press for 3 seconds to open the parameters menu.
2. Use **▲** or **▼** to select the parameter to be changed.
3. **▶** Press to display the parameter value.
4. Press **▶** to select the parameter value to be changed.
 - ▶ The value flashes.
5. **▲** Or press **▼** to change the parameter value.
6. **Press ▶** to save the changed parameter value.
7. Press **◀** to return to the parameters menu.
8. Repeat steps **2-7** to change more parameters.
9. If all parameters have been set, press **◀** to exit the parameters menu.

5.2 Parameter overview

The parameters described here can be set via the keypad on the control unit. Further settings can be made via the OSI.

Parameter	Display	Value range/ unit	Values (default = bold)	Explanation
Number of door leaves	DL	1-2	1	1-leaf
			2	2-leaf
Operator locking device	L I	0-4	0	None
			1	Standard locking device
			2	Magnetic lock
			3	Fail-safe locking
Door lock	L2	0-1	4	Fail-secure locking
			0	None
Program mode	P	0-1	1	Combined locking
			0	Standard
Operating mode switch type	P5	0/1/3/4	1	Fire protection function
			0	Conventional PGS
			1	EPS-CAN
			3	DPI/OSI only
Battery mode	A	0-2	4	EPS-CAN/DPI/OSI
			0	No battery
			1	Emergency close
			2	Emergency open
Emergency closing in exit	EF	0-1	0	No
			1	Yes
Locking mode	PL	0-3	0	Locking only in the Off operating mode
			1	Locking in the Off and Exit operating modes
			2	Locking in the Automatic and Partial Open and Off operating modes
			3	Locking in the Off, Automatic, Exit and Partial open operating modes

Parameter	Display	Value range/ unit	Values (default = bold)	Explanation
Power saving mode	CS	0-1	0 1	Off On
Acceleration in OPEN direction	AO	0-9	7	
Opening speed	SO	10-70 cm/second	50	Setting the opening speed
Acceleration in closing direction	AC	0-9	7	
Closing speed	SC	10-70 cm/second	25	Setting the closing speed
Braking ramp in OPEN direction	BO	0-9	5	
Force limitation in open	FO	5-31 10 N	15	Setting the force limitation in opening direction
Stopping force open position	PO	0-6	2	
Brake ramp in closing direction	BC	0-9	5	
Start-up delay	FS	0-10 seconds	0	
Hold-open time	DD	0-180 seconds	1	Setting the hold-open time
Night/bank hold-open time	DN	0-180 seconds	0	Setting the hold-open time for night/bank
Force limitation in closed position	FC	5-31 10 N	15	Setting the force limitation in the closing direction
End stop in the closing direction	LC	0-9	6	Setting the end stop in the closing direction

Parameter	Display	Value range/ unit	Values (default = bold)	Explanation
Locking force	P C	0-9	6	Setting the locking force
Sensitivity of the collision detection when the threshold value is undershot	C D	0-2	0	Low sensitivity
			1	Medium sensitivity
			2	High sensitivity
Sensitivity of the collision detection when the threshold value is exceeded	C D	0-2	0	Low sensitivity
			1	Medium sensitivity
			2	High sensitivity
Number of obstacles in the open direction	0 0	5-30	30	
Function Multiport 1	u i	1-14	0	No function
Default = 1			1	Output - status door closed
			2	Output - status door closed and locked
			3	Output - status door open
			4	Output - malfunction
			5	Output - info and malfunction
			6	Output - lock alarm
			7	Output - doorbell contact
			8	Output - Status No faults in unit
			9	Output - Service LED
			10	Input - Night/bank
			11	Input - key switch 1 left
			12	Input - key switch 1 right
			13	Input - fire protection closing
			14	Input - soft reset
Function Multiport 2	u 2			
Default = 10				

Parameter	Display	Value range/ unit	Values (default = bold)	Explanation
Function Multiport 1 - active input level	n1	0-3	0	Low active normally open
Function Multiport 2 - active input level	n2		1 2 3	High active normally open Low active normally closed High active normally closed
Key switch function right short	rS	0-16	1	0 No function 1 Night/Bank
Key switch function right long	rL	0-16	10	9 Off operating mode 10 Automatic operating mode
Key switch function left short	lS	0-16	0	11 Operating mode output 12 Partial open operating mode
Key switch function left long	lL	0-16	9	13 Permanent open operating mode 14 Switch to the previous operating mode 15 Unlock EPS-CAN 16 Lock EPS-CAN
Doorbell contact functionality	bF	0-3	0	0 No doorbell function 1 Rings on entry 2 Rings on exit
Sensor test	Sf	0-8	3 0	Rings in both directions Off 1 SCE (high active) 2 MCE (high active) 3 SCE + MCE (high active) 4 SCE (low active) 5 MCE (low active) 6 SCE + MCE (low active) 7 SCE (high active) + MCE (low active) 8 SCE (low active) + MCE (low active)

Parameter	Display	Value range/ unit	Values (default = bold)	Explanation
COM 1	C I	0-3	0 1	Off DPI/OSI
Factory settings setup	SL	1-3	1	Reset configuration and travel parameters
			2	Level 1 and special functions
			3	Level 2 and passwords, operating data, CAN and historical data
CAN reset	CR	0-1	0	Activation
Door pilot reset	dr	0-1	1	Set value for execution to 1
			0	Activation
Door weight	PO		1	Set value for execution to 1
				Shows the taught-in door weight in kg
Service cycles counter via control panel	CS	0-1	0	Activation
			1	Service cycles counter is reset
Delete error memories	EC	0-1	0	
			1	Set value for deletion to 1
Service mode	SE	0-2	0	Not active
			1	Service Mode 1
			2	Service Mode 2

6 Information and error display

The information (In) and errors (E) are displayed on the 7-segment display on the DRIVE CUBE. The Operator Service Interface can be used to read out the information and errors. Data are transmitted with RS232 via the RJ12 bushing on the control unit.

Display	Meaning/cause	Troubleshooting/possible causes
In 01	Obstacle in opening direction	<ul style="list-style-type: none"> • Remove obstacle • Check floor guide • Check toothed belt
In 02	Obstacle in closing direction	<ul style="list-style-type: none"> • Adjust obstacle detection and force limitation settings • Check mechanics and electronics of locking device/drive
In 09	Door weight too high	<ul style="list-style-type: none"> • Check door weight • Check structure of the door system for stiffness • Repeat teach-in run
In 18	Output stage IC has overheated and switched itself off	<ul style="list-style-type: none"> • Check control unit for overheating
In 23	Lock alarm floor locks locked	<ul style="list-style-type: none"> • Check lock
In 30	No power supply	<ul style="list-style-type: none"> • Check power supply
In 53	The toothed belt has jumped	<ul style="list-style-type: none"> • Check toothed belt tension • Replace toothed belt if necessary • Carry out a teach-in run afterwards
In 64	Fire protection closures	<ul style="list-style-type: none"> • Check fire alarm systems
In 68	Firmware download error	<ul style="list-style-type: none"> • Re-download firmware
In 99	Unknown CAN device detected	<ul style="list-style-type: none"> • Check the settings of all CAN devices (DIP switches) • Check whether third-party hardware is connected • Carry out a CAN reset if necessary

Display	Meaning/cause	Troubleshooting/possible causes
E0 00	Control unit is error-free	
E0 01	Door jammed in opening direction	<ul style="list-style-type: none"> • Incorrect zeroing • Remove obstacle • Check floor guide • Check toothed belt • Adjust obstacle detection and force limitation settings • Check mechanics and electronics of locking device/drive
E0 02	Door jammed in closing direction	<ul style="list-style-type: none"> • End stopper moved • Remove obstacle • Check floor guide • Check toothed belt • Adjust obstacle detection and force limitation settings • Check mechanics and electronics of locking device/drive
E0 05	Device identifier incorrect	<ul style="list-style-type: none"> • Perform network reset* • If the error occurs again, replace the control unit
E0 07	27 V controller overvoltage/undervoltage	<ul style="list-style-type: none"> • Perform network reset* • If the error occurs again, replace the control unit
E0 08	Ballast circuit	<ul style="list-style-type: none"> • Perform network reset* • If the error occurs again, replace the control unit
E0 09	Teach-in run not completed	<ul style="list-style-type: none"> • Repeat teach-in run
E0 10	Drive	<ul style="list-style-type: none"> • Check drive wiring • Replace drive or control unit
E0 13	Overcurrent	<ul style="list-style-type: none"> • Check drive wiring • Replace drive or control unit if necessary
E0 14	Drive pulse pattern	<ul style="list-style-type: none"> • Perform network reset* • If the error occurs again, replace the control unit
E0 17	No drive undervoltage power supply	<ul style="list-style-type: none"> • Check power supply or power supply unit

Display	Meaning/cause	Troubleshooting/possible causes
E0 18	IC drive output stage	<ul style="list-style-type: none"> • Replace control unit
E0 19	Drive overvoltage	<ul style="list-style-type: none"> • Check power supply or power supply unit
E0 21	Unlock operator locking device	<ul style="list-style-type: none"> • Locking device type adjusted correctly? • Locking device correctly adjusted mechanically?
E0 22	Lock operator locking device	<ul style="list-style-type: none"> • Check wiring
E0 23	Lock alarm	<ul style="list-style-type: none"> • Check lock • Door locked?
E0 24	Unlock door lock	<ul style="list-style-type: none"> • Locking device type adjusted correctly?
E0 25	Lock the door lock	<ul style="list-style-type: none"> • Locking device correctly adjusted mechanically? • Check wiring
E0 31	Operating mode switch	<ul style="list-style-type: none"> • Check wiring and function of the operating mode switch
E0 34	EPS-CAN	<ul style="list-style-type: none"> • Replace operating mode switch if necessary
E0 41	Sensor SCE 1	
E0 42	Sensor SCE 2	<ul style="list-style-type: none"> • Check sensor wiring
E0 43	Sensor MCE 1	<ul style="list-style-type: none"> • Check sensor parameters
E0 44	Sensor MCE 2	<ul style="list-style-type: none"> • Replace sensor if necessary
E0 51	Hall effect sensor	<ul style="list-style-type: none"> • Check drive wiring • Replace drive if necessary
E0 53	Toothed belt	<ul style="list-style-type: none"> • Incorrect zeroing • End stopper moved • Check toothed belt tension • Replace toothed belt if necessary • Carry out a teach-in run afterwards
E0 54	Zero point detection failed	<ul style="list-style-type: none"> • Check toothed belt • Perform network reset*

Display	Meaning/cause	Troubleshooting/possible causes
E0 69	Firmware update	<ul style="list-style-type: none"> • Install firmware via Operator Service Interface • Replace control unit if necessary
E0 71	EEProm memory check failed	<ul style="list-style-type: none"> • Select factory setting • Replace control unit if necessary
E0 72	Second shutdown path	
E0 74	Watchdog	<ul style="list-style-type: none"> • Replace control unit
E0 81	Battery undervoltage	<ul style="list-style-type: none"> • Check wiring • Charge battery • Replace battery if necessary
E0 82	Battery overvoltage	<ul style="list-style-type: none"> • Check battery charging voltage • Replace control unit if necessary
E0 84	Battery charging circuit	<ul style="list-style-type: none"> • Replace control unit if necessary
E0 85	Battery missing	<ul style="list-style-type: none"> • Check battery • Check wiring • Replace battery if necessary
E0 86	Battery test failed	<ul style="list-style-type: none"> • Check battery • Replace battery if necessary
E0 91	CAN BUS communication is disrupted	<ul style="list-style-type: none"> • Check connectors and wiring of the CAN participants • Perform network reset* • If the error occurs again, perform a CAN reset • Check firmware version for latest version • Replace control unit or CAN participant
E0 99	A device was detected on the CAN BUS that cannot be assigned to the stored device table. The table of devices that cannot be assigned is full and no more devices can be stored	<ul style="list-style-type: none"> • Perform control unit reset • Perform CAN reset if this occurs repeatedly

Perform network reset

1. Switch off the power supply
2. Remove the battery (if present)
3. Connect the battery (if present)
4. Switch on the power supply

Access Automation Solutions

Entrance Automation
Entrance Security
Glass Partition Walls



Access Control Solutions

Escape and Rescue Systems
Lodging Systems
Electronic Access & Data



Access Hardware Solutions

Door Closers
Architectural Hardware
Mechanical Key Systems
Glass Door Fittings



Services

Technical Support
Installation and commissioning
Maintenance and Repair



Sustainability

We are committed to fostering a sustainable development along our entire value chain in line with our economic, environmental and social responsibilities toward current and future generations. We seek an open, transparent dialogue with all stakeholders to define strategies and actions based on clear targets and continuous improvement, and we actively report on our progress.



dormakaba.com.tr

Warehouse address:

Beylikdüzü OSB, 8. Cd.
Mermerciler Sanayi Sitesi No:1
34524 Beylikdüzü/İstanbul,
Türkiye

Headquarters address:

dormakaba Kapı ve Güvenlik Sistemleri
San. ve Tic. A.Ş.

Kağıthane Ofispark, B2 Blok, K:5/30
Merkez Mah. Bağlar Cad. No:14
34406 Kağıthane/İstanbul

T +90 212 332 00 00

info.tr@dormakaba.com